C-A OPERATIONS PROCEDURES MANUAL

4.96.2 Critical Device Subsystem Response Checklist For Peers 3, 23 and 25 in Building 921, 912, 911 and H10 House

	Text Pages 1 th	_		
HPC No.	Date	Page Nos.	Initials	
				_
				_
				_
				Revision 00
	Approved by:	AGS Department Ch		 Date

A. McGeary

4.96.2 CRITICAL DEVICE SUBSYSTEM RESPONSE CHECKLIST FOR PEERS 3, 23 AND 25 IN BUILDING 921, 912, 911 AND H10 HOUSE

1. Purpose and Scope

Specifies the procedure to be employed during periodic validation of the PASS Access Control System Mode Responses.

2. <u>Responsibilities</u>

- 2.1 The AGS or RHIC Safety Systems Group Leader shall ensure that this procedure is executed, at no greater than six month intervals, or at such times as required by the RSC.
- 2.2 The AGS or RHIC Safety Systems Group Leader shall review and initial the completed procedure checklist.
- 2.3 The AGS or RHIC RSC Chairman (or his designee) shall review the test results.
- 2.4 Members of the AGS or RHIC Safety Systems Group shall, as designated, conduct and document this procedure.
- 2.5 The software engineers shall ensure the configuration control of the software tested.

3. Prerequisites

- 3.1 This procedure shall only be exercised after successful completion of Uup, Udn, VT, V1 and MUON Gate, Crash and Chipmunk test procedures.
- 3.2 This procedure may only be executed by members of the AGS or RHIC Safety System group whose training is shown as "valid" in the a Department or Project Training Database.
- 3.3 Three trained individuals are required to perform this procedure. One team member (Signal verifier) will work from the Control Room; the second (Inspector 1) and third (Inspector 2) will work in the power supply houses.
- 3.4 The critical devices UD1,2 P.S., UD1,2 440V DISCONNECT, H10 Extraction P.S., V1D1, V1D2 P.S.'s, BF6 and DH2,3 P.S.'s must be ready for energization at the appropriate step of this procedure.

AGS-OPM 4.96.2 (Y)

Revision 00

July 15, 1998

	3.5	Prior to execution of this procedure, the BTA beam line shall be placed in a safe off condition by performing "Lockout/Tagout for Radiation Safety (RS LOTO)" (AGS OPM 9.1.16).
		RS LOTO of BTA performed
	3.6	Programs loaded Divisions A & B for Peers 3, 23, & 25; and recorded in PASS Engineering Change LogBook.
	3.7	Run switches Peers 3, 23, & 25 RSC Red Tagged and Taped by AGS Safety Systems Group Leader Engineers. RS LOTO Applied Div A: Peer 3 Peer 25 RS LOTO Applied Div B: Peer 3 Peer 23 Peer 25 RS LOTO Development System Access Connector A Tag #
		RS LOTO Development System Access Connector B Tag #
	3.8	Notify the Operations Coordinator (OC) or the Main Control Room (MCR) supervisor that the critical devices are being tested.
4.	Precau	tions
	None	
5.	Proced	l <u>ure</u>
	5.1	From PASS Engineering Change Log Book, record software installed Peers 3, 23 & 25, both Divisions A & B. Division A Compiler version Division B Compiler version Peer 3 Div A Program Version: Save Date Peer 23 Div B Program Version: Save Date Peer 23 Div B Program Version: Save Date Peer 25 Div A Program Version: Save Date Peer 25 Div A Program Version:
ΔGS	S_OPM /	Save Date
1100	, 01 141 4	.50.2 (1)

4.

5.

Peer 2.	5 Div B Program Version: Save Date
	NOTE: Mode selection is accomplished by Panelview.
Observation of	NOTE: critical devices is observed both on Panelview and at location of the critical device
PEER 3 C	RITICAL DEVICES - V1D1 PS, V1D2 PS, AGS ENABLE (P), AGS ENABLE (R)
5.2 <u>V1D1</u>	PS and V1D2 PS Critical Devices (Drawing C1028023)
5.2.1	Confirm that the Critical Devices V1D1 PS and V1D2 PS are labeled with orange security interlock signs, that the interconnects between the Critical Devices and the Building 921 Critical device Box(5470) is undamaged as are the RIO feeds from the PLC's.
	Orange tags present Mechanical inspection OK
5.2.2	With Peer3A and 3B in NO ACCESS (mode 24) observe that after 90 seconds that Critical Devices V1D1 PS and V1D2 PS are enabled. The RED "Security Interlock OK" lamp on the P.S.'s are on.
	V1D1 PS enabled by PASS V1D2 PS enabled by PASS RED lamp on V1D1 PS is on RED lamp on V1D2 PS is on V1D1 Indicates off Div A: Peer 3A in7 on V1D1 Indicates off Div B: Peer 3B in7 on V1D2 Indicates off Div A: Peer 3A in6 on V1D2 Indicates off Div B: Peer 3B in6 on
	5.2.2.1 Confirm that the V1D1 and V1D2 PS's can be turned on. V1D1 PS turned on V1D2 PS turned on V1D1 Indicates on Div A: Peer 3A in7 off V1D1 Indicates on Div B: Peer 3B in7 off
AGS-OPM 4.96.2 (Y	Revision 00 July 15, 1998

V1D2 Indicates on Div A: Peer 3A in6 off	
V1D2 Indicates on Div B: Peer 3B in 6 off	

A 1	4
N	OTO
т. и	vic

Relay K17, Terminal 5 is shown in this procedure as K17/5. Terminal 22 on the Main Strip is shown as 5470A/22

5.2.2.2 Both Divisions are necessary for V1D1 & V1D2 on:	
With Power Supplies on;	
Measure resistance K16/5 to 5470A/25.	
Less than 2 ohms	
Measure resistance K16/5 to 5470A/23.	
Less than 2 ohms	
Measure resistance K18/5 5470A/29.	
Less than 2 ohms	
Measure resistance K18/5 to 5470A/27.	
Less than 2 ohms	
5.2.2.3 Both Divisions assure V1D1 & V1D2 off:	
Set Peer 3A and 3B to C/A (mode 16) and observe V1D1 PS	and
V1D2 PS trip off.	
V1D1& V1D2 PS trip off	
V1D1 Red light off and PS will not come on	
V1D2 Red light off and PS will not come on	
Measure resistance K17/5 5470A/25.	
Greater than 100K ohms	
Measure resistance K17/5 5470A/23.	
Greater than 100K ohms	
Measure resistance K18/5 to 5470A/29.	
Greater than 100K ohms	
Measure resistance K18/5 to 5470A/27.	
Greater than 100K ohms	
5.2.2.4 Set Peer 3A and 3B to R/A (mode 8) and observe V1D1 PS a	ınd
V1D2 PS lamps.	
V1D1 Red light off and PS will not come on	
V1D2 Red light off and PS will not come on	
5.2.2.5 Set Peer 3A and 3B to Safe State (mode 2) and observe V1I	D1 PS
and V1D2 PS lamps.	
V1D1 Red light off and PS will not come on	
V1D2 Red light off and PS will not come on	
Y) Revisio	on 00

		5.2.2.6 Check readbacks respond for V1D1. Lift Term strip 5470A wire #23. Panel View indicates V1D1 on V1D1 Indicates on Div A: Peer 3A in7 off V1D1 Indicates on Div B: Peer 3B in7 off
		5.2.2.7 Check readbacks respond for V1D2. Lift Term strip 5470A wire #27. Panel View indicates V1D2 on V1D2 Indicates on Div A: Peer 3A in6 off V1D2 Indicates on Div B: Peer 3B in6 off
5.3	The fo	PS and V1D2 PS Critical Device Reachback to AGS llowing test will be done with peer23 in No Access, beam enabled state and 5 in Safe State, no reachback.
	5.3.1	Confirm that the Building 921 Critical device Box (5470) is mechanically sound and that the interconnects between this enclosure and the Security system junction box 5133 is undamaged as are the RIO feeds from the PLC's. The GREEN communication (COM) lamps on the RIO blocks should be ON.
		Mechanical inspection OK Peer 3A and 3B COM lamps on
	5.3.2	With Peer3A and 3B in SAFE STATE (mode2) for 2 minutes, confirm that Critical Devices are energized and Panelview indication.
		Measure resistance 5470A/13 to K2/5 Less than 2 ohms Measure resistance 5470A/15 to K2/5 Less than 2 ohms Measure resistance 5470A/14 to K8/5 Less than 2 ohms Measure resistance 5470A/16 to K8/5 Less than 2 ohms
		Panelview indicates AGS ENABLED by Peer 3
	5.3.3	With Peer3A and 3B in R/A (mode8) for 2 minutes, confirm that Critical Devices are enabled Panelview indicates AGS ENABLED by Peer 3
	5.3.4	With Peer3A and 3B in C/A (mode16) for 2 minutes, confirm that Critical Devices are enabled. Panelview indicates AGS ENABLED by Peer 3

ritical Devices are enabled.	ıt
allerview illulcates AGS ENABLED by Feel 5	
path 1 & 2.	
ritical Reachback Devices are enabled. Confirm that Output lamps O4 and	
Peer3A O4 and O5 go from on to off Peer3B O4 and O5 go from on to off Panelview shows AGS DISABLED by Peer 3 Measure resistance 5470A/13 to K2/5 Greater than 100K ohms Measure resistance 5470A/15 to K2/5 Greater than 100K ohms Measure resistance 5470A/14 to K8/5 Greater than 100K ohms Measure resistance 5470A/16 to K8/5 Greater than 100K ohms Measure resistance 5470A/16 to K8/5 Greater than 100K ohms	re
hation ving	Critical Reachback Devices are enabled. Confirm that Output lamps O4 an O5 are on for both Division "A" and "B" RIO blocks. Division "A" O4 is on O5 is on Division "B" O4 is on O5

5.4

Reconnect 5470A/28 and reset reach back via Panelview and restore mode.

5.4.2	Devices	eer3A and 3B in R/A (mode8) for 2 minutes, confirm that Critical BF6 and DH2,3 are enabled. Confirm that Output lamps O4 and O5 for both Division "A" and "B" RIO blocks.
		n "A" O4 is on O5 is on n "B" O4 is on O5 is on
	5.4.2.1	Lift wire 5470A/24 Peer3A O4 and O5 go from on to off Peer3B O4 and O5 go from on to off Panelview shows AGS DISABLED by Peer 3 Reconnect 5470A/24 and reset reach back via Panelview and restore mode.
	5.4.2.2	Lift wire 5470A/28 Peer3A O4 and O5 go from on to off Peer3B O4 and O5 go from on to off Panelview shows AGS DISABLED by Peer 3 Reconnect 5470A/28 and reset reach back via Panelview and
5.4.3	Devices	restore mode. eer3A and 3B in C/A (mode16) for 2 minutes, confirm that Critical as BF6 and DH2,3 are enabled. Confirm that Output lamps O4 and O5 for both Division "A" and "B" RIO blocks.
	Division	n "A" O4 is on O5 is on n "B" O4 is on O5 is on ew indicates AGS DISABLED by Peer 3
	5.4.3.1	Lift wire 5470A/24 Peer3A O4 and O5 go from on to off Peer3B O4 and O5 go from on to off Panelview shows AGS DISABLED by Peer 3 Reconnect 5470A/24 and reset reach back via Panelview and
		restore mode.

		Peer3A O4 and O5 go from on to off Peer3B O4 and O5 go from on to off Panelview shows AGS DISABLED by Peer 3
		Reconnect 5470A/28 and reset reach back via Panelview and restore mode.
		L DEVICES - AGS INJECTION ENABLE (1), AGS INJECTION STER INJECTION ENABLE (1), BOOSTER INJECTION ENABLE (2)
5.5	The fo	NJECTION ENABLE (1), AGS INJECTION ENABLE (2), llowing test will be done with Peer 3 and Peer 25 in SAFE STATE (no reach o AGS Injection Enable)
	5.5.1	With Peer 23A and 23B in NO ACCESS (mode 24) observe that after 90 seconds that AGS INJECTION ENABLE (1) and AGS INJECTION ENABLE (2) are enabled and Panelview so indicates.
		Measure resistance 5470A/13 to K4/5 Less than 2 ohms Measure resistance 5470A/15 to K4/5 Less than 2 ohms Measure resistance 5470A/14 to K10/5 Less than 2 ohms Measure resistance 5470A/16 to K10/5 Less than 2 ohms Measure resistance 5470A/16 to K10/5 Less than 2 ohms
		AGS INJECTION ENABLE (1) indicates: Peer 23A out7 on AGS INJECTION ENABLE (2) indicates: Peer 23A out6 on AGS INJECTION ENABLE (1) indicates: Peer 23B out7 on AGS INJECTION ENABLE (2) indicates: Peer 23B out6 on
		AGS INJECTION STATUS (1) indicates: Peer 23A in 7 on AGS INJECTION STATUS (2) indicates: Peer 23A in 6 on AGS INJECTION STATUS (1) indicates: Peer 23B in 7 on AGS INJECTION STATUS (2) indicates: Peer 23B in 6 on
		Panelview indicates AGS INJECTION (1) and (2) enabled by Peer 23
	5.5.2	Confirm that AGS INJECTION can be enabled
		AGS INJECTION STATUS (1) indicates: Peer 23A in 7 off AGS INJECTION STATUS (2) indicates: Peer 23A in 6 off AGS INJECTION STATUS (1) indicates: Peer 23B in 7 off AGS INJECTION STATUS (2) indicates: Peer 23B in 6 off

5.4.3.2 Lift wire 5470A/28

Revision 00 AGS-OPM 4.96.2 (Y) July 15, 1998

8

Both divisions assure AGS INJECTION disabled for C/A 5.5.3 Set Peer 23A and 23B to C/A (mode 16) and observe AGS Disabled. Measure resistance 5470A/13 to K4/5 Greater than 100k ohms Measure resistance 5470A/15 to K4/5 Greater than 100k ohms Measure resistance 5470A/14 to K10/5 Greater than 100k ohms _____ Measure resistance 5470A/16 to K10/5 Greater than 100k ohms _____ AGS INJECTION ENABLE (1) indicates: Peer 23A out7 off AGS INJECTION ENABLE (2) indicates: Peer 23A out6 off _____ AGS INJECTION ENABLE (1) indicates: Peer 23B out7 off _____ AGS INJECTION ENABLE (2) indicates: Peer 23B out6 off AGS INJECTION STATUS (1) indicates: Peer 23A in 7 on _____ AGS INJECTION STATUS (2) indicates: Peer 23A in 6 on _____ AGS INJECTION STATUS (1) indicates: Peer 23B in 7 on ______ AGS INJECTION STATUS (2) indicates: Peer 23B in 6 on _____ Both divisions assure AGS INJECTION disabled for R/A 5.5.4 Set Peer 23A and 23B to R/A (mode 8) and observe AGS Disabled. AGS INJECTION ENABLE (1) indicates: Peer 23A out7 off _____ AGS INJECTION ENABLE (2) indicates: Peer 23A out6 off _____ AGS INJECTION ENABLE (1) indicates: Peer 23B out7 off _____ AGS INJECTION ENABLE (2) indicates: Peer 23B out6 off _____ AGS INJECTION STATUS (1) indicates: Peer 23A in 7 on _____ AGS INJECTION STATUS (2) indicates: Peer 23A in 6 on AGS INJECTION STATUS (1) indicates: Peer 23B in 7 on _____ AGS INJECTION STATUS (2) indicates: Peer 23B in 6 on _____ Both divisions assure AGS INJECTION disabled for SAFE STATE Set Peer 23A and 23B to SAFE STATE (mode 2) and observe AGS Disabled.

AGS-OPM 4.96.2 (Y) Revision 00

9

AGS INJECTION ENABLE (1) indicates: Peer 23A out7 off _______AGS INJECTION ENABLE (2) indicates: Peer 23A out6 off ______

		AGS INJECTION ENABLE (1) indicates: Peer 23B out7 off
		AGS INJECTION ENABLE (2) indicates: Peer 23B out6 off
		AGS INJECTION STATUS (1) indicates: Peer 23A in 7 on
		AGS INJECTION STATUS (1) indicates: Peer 23A in/ on
		· ·
		AGS INJECTION STATUS (1) indicates: Peer 23B in 7 on
		AGS INJECTION STATUS (2) indicates: Peer 23B in6 on
5.6	BOOS	STER INJECTION ENABLE (1) and BOOSTER INJECTION ENABLE (2)
	5.6.1	0 11
		mechanically sound and that the GREEN communication (COM) lamps on the RIO blocks are ON.
	5.6.2	With Peer23A and 23B in SAFE STATE (mode 2) for 2 minutes, confirm
		that BOOSTER INJECTION ENABLE (1) and BOOSTER INJECTION
		ENABLE (2) and Panelview so indicates.
		Measure resistance terminal 2-4 to 2K2/1 Less than 2 ohms
		Measure resistance terminal 2-5 to 2K1/3 Less than 2 ohms
		Measure resistance terminal 1-4 to 1K2/1 Less than 2 ohms
		Measure resistance terminal 1-5 to 1K1/3 Less than 2 ohms
		BOOSTER INJECTION ENABLE (1) indicates:
		Peer 23A out7 on
		BOOSTER INJECTION ENABLE (2) indicates:
		Peer 23A out6 on
		BOOSTER INJECTION ENABLE (1) indicates:
		Peer 23B out7 on
		BOOSTER INJECTION ENABLE (2) indicates:
		Peer 23B out6 on
		Assuming Booster Injection is On:
		BOOSTER INJECTION STATUS (1) indicates:
		Peer 23A in 7 off
		BOOSTER INJECTION STATUS (2) indicates:
		Peer 23A in6 off
		BOOSTER INJECTION STATUS (1) indicates:
		Peer 23B in 7 off
		BOOSTER INJECTION STATUS (2) indicates:
		Peer 23B in6 off
		Develoisme in diseases Deceases Injusting and Liber Decease 22
		Panelview indicates Booster Injection enabled by Peer 23

5.6.3	With Peer23A and 23B in R/A (mode 8) for 2 minutes confirm that Booster Injection is enabled.
	BOOSTER INJECTION ENABLE (1) indicates: Peer 23A out7 on
	BOOSTER INJECTION ENABLE (2) indicates:
	Peer 23A out6 on BOOSTER INJECTION ENABLE (1) indicates:
	Peer 23B out7 on BOOSTER INJECTION ENABLE (2) indicates: Peer 23B out6 on
	Panelview indicates Booster Injection enabled by Peer 23
5.6.4	With Peer23A and 23B in C/A (mode 16) for 2 minutes confirm that Booster Injection is enabled.
	Booster injection is enabled.
	BOOSTER INJECTION ENABLE (1) indicates:
	Peer 23A out7 on
	BOOSTER INJECTION ENABLE (2) indicates:
	Peer 23A out6 on
	BOOSTER INJECTION ENABLE (1) indicates:
	Peer 23B out7 on
	BOOSTER INJECTION ENABLE (2) indicates:
	Peer 23B out6 on
	Panelview indicates Booster Injection enabled by Peer 23
	nat incorrect status of AGS Injection reaches back to interlock Booster on path 1 and 2.
5.7.1	With Peer23A and 23B in SAFE STATE (mode 2) for 2 minutes, confirm that Booster Injection (1) AND BOOSTER Injection (2) are enabled. Confirm that at Booster Injection Critical Device Box in Building 911 Output lamps O6 and O7 are ON for both Division "A" and "B".
	5.7.1.1 In Building 921 lift wire 5470A17 to lose AGS Injection Off (1) status At Peer 23 Critical Device Box in building 911: Peer 23A O6 and O7 go from ON to OFF Peer 23B O6 and O7 go from ON to OFF
	Panelview indicates Reach back to Booster Injection

5.7

	5.7.1.2	Measure resistance terminal 2-4 to 2K2/1
		Greater than 100k ohms Measure resistance terminal 2-5 to 2K1/3
		Greater than 100k ohms
		Measure resistance terminal 1-4 to 1K2/1
		Greater than 100k ohms
		Measure resistance terminal 1-5 to 1K1/3
		Greater than 100k ohms
	5.7.1.3	Reconnect 5470A/17 and reset reach back via Panelview and
		restore mode
	5.7.1.4	In Building 921 lift wire 5470A18 to lose AGS Injection Off (2)
		status
		At Peer 23 Critical Device Box in building 911:
		Peer 23A O6 and O7 go from ON to OFF
		Peer 23B O6 and O7 go from ON to OFF
		Panelview indicates Reach back to Booster Injection
	5.7.1.5	Measure resistance terminal 2-4 to 2K2/1
		Greater than 100k ohms
		Measure resistance terminal 2-5 to 2K1/3
		Greater than 100k ohms
		Measure resistance terminal 1-4 to 1K2/1
		Greater than 100k ohms Measure resistance terminal 1-5 to 1K1/3
		Greater than 100k ohms
	5716	Reconnect 5470A/17 and reset reach back via Panelview and
	3.7.1.0	restore mode
5.7.2	With Pe	eer23A and 23B in R/A (mode 8) for 2 minutes, confirm that Booster
		n (1) AND BOOSTER Injection (2) are enabled. Confirm that at
		Injection Critical Device Box in Building 911 Output lamps O6 and
	O7 are 0	ON for both Division "A" and "B".
	5.7.2.1	In Building 921 lift wire 5470A17 to lose AGS Injection Off (1) status
		At Peer 23 Critical Device Box in building 911:
		Peer 23A O6 and O7 go from ON to OFF
		Peer 23B O6 and O7 go from ON to OFF
		Panelview indicates Reach back to Booster Injection
AGS-OPM 4.96.2 (Y))	Revision 00
		July 15, 1998

	5.7.2.2	Reconnect 5470A/17 and reset reach back via Panelview and restore mode			
	5.7.2.3	In Building 921 lift wire 5470A18 to lose AGS Injection Off (2) status At Peer 23 Critical Device Box in building 911: Peer 23A O6 and O7 go from ON to OFF Peer 23B O6 and O7 go from ON to OFF			
		Panelview indicates Reach back to Booster Injection			
	5.7.2.4	Reconnect 5470A/18 and reset reach back via Panelview and restore mode			
5.7.3	With Peer23A and 23B in C/A (mode 16) for 2 minutes, confirm that Booster Injection (1) AND BOOSTER Injection (2) are enabled. Confirm that at Booster Injection Critical Device Box in Building 911 Output lamps O6 and O7 are ON for both Division "A" and "B".				
	5.7.3.1	In Building 921 lift wire 5470A17 to lose AGS Injection Off (1) status At Peer 23 Critical Device Box in building 911: Peer 23A O6 and O7 go from ON to OFF Peer 23B O6 and O7 go from ON to OFF			
		Panelview indicates Reach back to Booster Injection			
	5.7.3.2	Reconnect 5470A/17 and reset reach back via Panelview and restore mode			
	5.7.3.3	In Building 921 lift wire 5470A18 to lose AGS Injection Off (2) status At Peer 23 Critical Device Box in building 911: Peer 23A O6 and O7 go from ON to OFF Peer 23B O6 and O7 go from ON to OFF			
		Panelview indicates Reach back to Booster Injection			
	5.7.3.4	Reconnect 5470A/18 and reset reach back via Panelview and restore mode			

AGS-OPM 4.96.2 (Y) Revision 00

13

PEER 25 CRITICAL DEVICES - UD1,2 P.S. (UD1,2 AC), UD1,2 440 VAC DISCONNECT (UD1,2 DC), H10 P.S., AGS INJECTION ENABLE (1), AGS INJECTION ENABLE (2)

UD1,2	2 P.S., UD1,2 440 VAC DISCONNECT
5.8.1	With Peer 25A and B in NO ACCESS (mode 24) observe after 90 seconds that UD1,2 P.S. and UD1,2 440 VAC DISCONNECT are enabled and Panelview so indicates. Note that 440 VAC DISCONNECT contactor closes after 90 seconds without further command.
5.8.2	At the Critical Device Box in Building 912 near UD1,2 P.S. perform the measurements listed.:
	Measure resistance terminal 2-4 to 2K2/1 Less than 2 ohms Measure resistance terminal 2-5 to 2K1/3 Less than 2 ohms Measure resistance terminal 1-4 to 1K2/1 Less than 2 ohms Measure resistance terminal 1-5 to 1K1/3 Less than 2 ohms
	UD1,2 ENABLE AC indicates: Peer 25A out 7 on UD1,2 ENABLE DC indicates: Peer 25A out 6 on UD1,2 ENABLE AC indicates: Peer 25B out 7 on UD1,2 ENABLE DC indicates: Peer 25B out 6 on
	UD1,2 STATUS AC indicates: Peer 25A in 7 on UD1,2 STATUS DC indicates: Peer 25A in 6 off UD1,2 STATUS AC indicates: Peer 25B in 7 on UD1,2 STATUS DC indicates: Peer 25B in 6 off
	Panelview indicates UD1,2 AC and DC enabled by Peer 25 and UD1,2 DC ON
5.8.3	Confirm that UD1,2 P.S. can be turned on.
	UD1,2 AC STATUS indicates: Peer 25A in7 off UD1,2 AC STATUS indicates: Peer 25B in7 off Panelview indicates UD1,2 AC and DC on
5.8.4	Both divisions assure UD1,2 AC and DC disabled for C/A Set Peer 25A and 25B to C/A (mode 16) and observe UD1,2 Disabled.

AGS-OPM 4.96.2 (Y)

5.8

Greater than 100k ohms _____

Greater than 100k ohms _____

Measure resistance terminal 2-4 to 2K2/1

Measure resistance terminal 2-5 to 2K1/3

	Measure resistance terminal 1-4 to 1K2/1 Greater than 100k ohms
	Measure resistance terminal 1-5 to 1K1/3
	Greater than 100k ohms
	UD1,2 ENABLE AC indicates : Peer 25A out7 off
	UD1,2 ENABLE DC indicates: Peer 25A out6 off
	UD1,2 ENABLE AC indicates: Peer 25B out7 off
	UD1,2 ENABLE DC indicates : Peer 25B out6 off
	UD1,2 STATUS AC indicates: Peer 25A in7 on
	UD1,2 STATUS DC indicates: Peer 25A in6 on
	UD1,2 STATUS AC indicates: Peer 25B in7 on
	UD1,2 STATUS DC indicates: Peer 25B in6 on
5.8.5	Both divisions assure UD1,2 AC and DC disabled for R/A Set Peer 25A and 25B to R/A (mode 8) and observe UD1,2 Disabled.
	UD1,2 ENABLE AC indicates : Peer 25A out7 off
	UD1,2 ENABLE DC indicates: Peer 25A out6 off
	UD1,2 ENABLE AC indicates : Peer 25B out7 off
	UD1,2 ENABLE DC indicates : Peer 25B out6 off
	UD1,2 STATUS AC indicates: Peer 25A in7 on
	UD1,2 STATUS DC indicates: Peer 25A in6 on
	UD1,2 STATUS AC indicates: Peer 25B in7 on
	UD1,2 STATUS DC indicates: Peer 25B in6 on
5.8.6	Both divisions assure UD1,2 AC and DC disabled for SAFE STATE Set Peer 25A and 25B to SAFE STATE (mode 2) and observe UD1,2 Disabled.
	UD1,2 ENABLE AC indicates : Peer 25A out7 off
	UD1,2 ENABLE DC indicates : Peer 25A out6 off
	UD1,2 ENABLE AC indicates: Peer 25B out7 off
	UD1,2 ENABLE DC indicates : Peer 25B out6 off
	UD1,2 STATUS AC indicates: Peer 25A in7 on
	UD1,2 STATUS DC indicates: Peer 25A in6 on
	UD1,2 STATUS AC indicates: Peer 25B in7 on
	UD1,2 STATUS DC indicates: Peer 25B in6 on

AGS-OPM 4.96.2 (Y)

Revision 00

July 15, 1998

5.	0	LI1	Λ	P.S.	
J.	.9	пі	v	Г.Э.	

5.9.1	With Peer 25A and B in NO ACCESS (mode 24) observe after 90 seconds
	that H10 P.S. is enabled and Panelview so indicates

	that H10 P.S. is enabled and Panelview so indicates
5.9.2	At the Critical Device Box in H10 House near H10 P.S perform the measurements listed.:
	Measure resistance terminal 1-4 to 1K2/1 Less than 2 ohms Measure resistance terminal 1-5 to 1K1/3 Less than 2 ohms
	H10 P.S. ENABLE indicates: Peer 25A out7 on H10 P.S. ENABLE indicates: Peer 25B out7 on
	H10 P.S. STATUS indicates : Peer25A in7 on H10 P.S. STATUS indicates : Peer25B in7 on
	Panelview indicates H10 P.S. enabled by Peer 25
5.9.3	Confirm that H10 P.S. can be turned on.
	H10 P.S. STATUS indicates: Peer25A in 7 offH10 P.S. STATUS indicates: Peer25B in 7 off
	Panelview indicates H10 P.S. On
5.9.4	Both divisions assure H10 P.S. disabled for C/A Set Peer 25A and 25B to C/A (mode 16) and observe H10 P.S. Disabled.
	Measure resistance terminal 1-4 to 1K2/1 Greater than 100k ohms Measure resistance terminal 1-5 to 1K1/3
	Greater than 100k ohms
	H10 P.S. ENABLE indicates: Peer 25A out7 off H10 P.S. ENABLE indicates: Peer 25B out7 off
	H10 P.S. STATUS indicates: Peer 25A in 7 on H10 P.S. STATUS indicates: Peer 25B in 7 on

5.9.5 Both divisions assure H10 P.S. disabled for R/A Set Peer 25A and 25B to R/A (mode 8) and observe H10 P.S. Disabled.

Revision 00 AGS-OPM 4.96.2 (Y)

16

		Measure resistance terminal 1-4 to 1K2/1 Greater than 100k ohms
		Measure resistance terminal 1-5 to 1K1/3 Greater than 100k ohms
		H10 P.S. ENABLE indicates : Peer 25A out7 off
		H10 P.S. ENABLE indicates: Peer 25B out7 off
		H10 P.S. STATUS indicates: Peer 25A in7 on H10 P.S. STATUS indicates: Peer 25B in7 on
	5.9.6	Both divisions assure H10 P.S. disabled for SAFE STATE Set Peer 25A and 25B to SAFE STATE (mode 217) and observe H10 P.S. Disabled.
		Measure resistance terminal 1-4 to 1K2/1 Greater than 100k ohms
		Measure resistance terminal 1-5 to 1K1/3 Greater than 100k ohms
		H10 P.S. ENABLE indicates: Peer 25A out7 off
		H10 P.S. ENABLE indicates: Peer 25B out7 off
		H10 P.S. STATUS indicates: Peer 25A in 7 on H10 P.S. STATUS indicates: Peer 25B in 7 on
5.10	The fol	NJECTION ENABLE (1) and AGS INJECTION ENABLE (2) llowing test will be done with Peer 3 in SAFE STATE (no reach back to njection Enable) and Peer 23 in NO ACCESS mode.
	5.10.1	Confirm that the Building 921 Critical Device box (5470) is mechanically sound and that the GREEN communication (COM) lamps on the RIO blocks are ON.
	5.10.2	In Building 921, with Peer25A and 25B in SAFE STATE (mode 2) for 2 minutes, confirm AGS INJECTION ENABLE (1) and AGS INJECTION ENABLE (2) and Panelview so indicates.
		Measure resistance 5470A/13 to K6/9 Less than 2 ohms
		Measure resistance 5470A/15 to K6/9 Less than 2 ohms
		Measure resistance 5470A/14 to K11/5 Less than 2 ohms Measure resistance 5470A/16 to K11/5 Less than 2 ohms
		AGS INJECTION ENABLE (1) indicates: Peer 25A out7 on
		AGS INJECTION ENABLE (1) indicates: Peer 25A out/ on
		AGS INJECTION ENABLE (1) indicates: Peer 25B out7 on
AGS-OPM 4.	96.2 (Y)	Revision 00 July 15, 1998

		AGS INJECTION ENABLE (2) indicates : Peer 25B out6 on
		Assuming AGS Injection is On:
		AGS INJECTION STATUS (1) indicates: Peer 25A in 7 offAGS INJECTION STATUS (2) indicates: Peer 25A in 6 off
		AGS INJECTION STATUS (2) indicates: Feet 25A into off
		AGS INJECTION STATUS (1) indicates: Feet 25B in 7 off
		Add indection States (2) indicates, teel 23b indoit
		Panelview indicates AGS Injection enabled by Peer 25
	5.10.3	With Peer25A and 25B in R/A (mode 8) for 2 minutes confirm that AGS Injection is enabled.
		AGS INJECTION ENABLE (1) indicates: Peer 25A out7 on
		AGS INJECTION ENABLE (1) indicates: 1 cer 25A out on
		AGS INJECTION ENABLE (1) indicates: Peer 25B out7 on
		AGS INJECTION ENABLE (2) indicates: Peer 25B out on
		Tiob invite from Entrible (2) indicates . Feet 25b outo on
		Panelview indicates AGS Injection enabled by Peer 25
	5.10.4	With Peer25A and 25B in C/A (mode 16) for 2 minutes confirm that AGS Injection is enabled.
		AGS INJECTION ENABLE (1) indicates: Peer 25A out7 on AGS INJECTION ENABLE (2) indicates: Peer 25A out6 on
		AGS INJECTION ENABLE (1) indicates : Peer 25B out7 on AGS INJECTION ENABLE (2) indicates : Peer 25B out6 on
		Panelview indicates AGS Injection enabled by Peer 25
5.11		at incorrect status of UD1,2 AC, UD1,2 DC or H10 P.S. reaches back to ck AGS Injection (1) and AGS Injection (2) for Peer 25 in SAFE STATE 2).
	5.11.1	With Peer 25A and Peer 25B in SAFE STATE (mode 2) for 2 minutes, confirm that AGS INJECTION (1) AND AGS INJECTION (2) are enabled. Confirm that Building 921 Critical Device Box (5470) Peer 25 RIO Output lamps O6 and O7 lamps are On for both Division "A" and "B".
		Peer 25A O6 is On Peer 25A O7 is On Peer 25B O6 is On Peer 25B O7 is On

5.11.1.1	In UD1,2 Critical Device Box lift wire 1-3 to lose UD1,2 AC Off
	status.
	At 5470 box in building 921:
	Peer 25A O6 and O7 go from ON to OFF
	Peer 25B O6 and O7 go from ON to OFF
	Panelview indicates Reach back to AGS Injection
5.11.1.2	Measure resistance 5470A/13 to K6/9
	Greater than 100k ohms
	Measure resistance 5470A/15 to K6/9
	Greater than 100k ohms
	Measure resistance 5470A/14 to K11/5
	Greater than 100k ohms
	Measure resistance 5470A/16 to K11/5
	Greater than 100k ohms
5.11.1.3	Reconnect 1-3 in UD1,2 Box and reset reach back via Panelview and restore mode
5.11.1.4	In UD1,2 Critical Device Box lift wire 2-3 to lose UD1,2 DC Off status. At 5470 box in building 921: Peer 25A O6 and O7 go from ON to OFF Peer 25B O6 and O7 go from ON to OFF
	Panelview indicates Reach back to AGS Injection
5 11 1 5	Measure resistance 5470A/13 to K6/9
01111110	Greater than 100k ohms
	Measure resistance 5470A/15 to K6/9
	Greater than 100k ohms
	Measure resistance 5470A/14 to K11/5
	Greater than 100k ohms
	Measure resistance 5470A/16 to K11/5
	Greater than 100k ohms
5.11.1.6	Reconnect 2-3 in UD1,2 Box and reset reach back via Panelview
	and restore mode
	
5.11.1.7	In H10 Critical Device Box lift wire 1-3 to lose H10 Off status. At 5470 box in building 921:
	Peer 25A O6 and O7 go from ON to OFF
	Peer 25B O6 and O7 go from ON to OFF

5.12	Test that incorrect status of UD1,2 AC, UD1,2 DC or H10 P.S. reaches back to interlock AGS Injection (1) and AGS Injection (2) for Peer 25 in R/A (mode 8)				
	5.12.1	With Peer 25A and Peer 25B in R/A (mode 8) for 2 minutes, confirm that AGS INJECTION (1) AND AGS INJECTION (2) are enabled. Confirm that Building 921 Critical Device Box (5470) Peer 25 RIO Output lamps O6 and O7 lamps are On for both Division "A" and "B".			
		Peer 25A	O6 is On O7 is On O6 is On		
		Peer 25B O7 is On			
		5.12.1.1	In UD1,2 Critical Device Box lift wire 1-3 to lose UD1,2 AC Off status. At 5470 box in building 921: Peer 25A O6 and O7 go from ON to OFF Peer 25B O6 and O7 go from ON to OFF		
			Panelview indicates Reach back to AGS Injection		
		5.12.1.2	Measure resistance 5470A/13 to K6/9 Greater than 100k ohms Measure resistance 5470A/15 to K6/9 Greater than 100k ohms Measure resistance 5470A/14 to K11/5 Greater than 100k ohms Measure resistance 5470A/16 to K11/5 Greater than 100k ohms		
		5.12.1.3	Reconnect 1-3 in UD1,2 Box and reset reach back via Panelview and restore mode		
		5.12.1.4	In UD1,2 Critical Device Box lift wire 2-3 to lose UD1,2 DC Off status At 5470 box in building 921: Peer 25A O6 and O7 go from ON to OFF Peer 25B O6 and O7 go from ON to OFF		
			Panelview indicates Reach back to AGS Injection		
		5.12.1.5	Measure resistance 5470A/13 to K6/9		

Measure resistance 5470A/15 to K6/9

Greater than 100k ohms __

			Greater than 100k ohms
			Measure resistance 5470A/14 to K11/5
			Greater than 100k ohms
			Measure resistance 5470A/16 to K11/5
			Greater than 100k ohms
		5.12.1.6	Reconnect 2-3 in UD1,2 Box and reset reach back via Panelview and restore mode
		5.12.1.7	In H10 Critical Device Box lift wire 1-3 to lose H10 Off status. At 5470 box in building 921: Peer 25A O6 and O7 go from ON to OFF
			Peer 25B O6 and O7 go from ON to OFF
			Panelview indicates Reach back to AGS Injection
		5.12.1.8	Measure resistance 5470A/13 to K6/9
			Greater than 100k ohms
			Measure resistance 5470A/15 to K6/9
			Greater than 100k ohms
			Measure resistance 5470A/14 to K11/5
			Greater than 100k ohms
			Measure resistance 5470A/16 to K11/5
			Greater than 100k ohms
		5.12.1.9	Reconnect 1-3 in H10 Box and reset reach back via Panelview and restore mode
5.13			et status of UD1,2 AC, UD1,2 DC or H10 P.S. reaches back to jection (1) and AGS Injection (2) for Peer 25 in C/A (mode 16).
	5.13.1	AGS INJ Building	r 25A and Peer 25B in C/A (mode 16) for 2 minutes, confirm that ECTION (1) AND AGS INJECTION (2) are enabled. Confirm that 921 Critical Device Box (5470) Peer 25 RIO Output lamps O6 and are On for both Division "A" and "B".
		Peer 25A Peer 25B	O6 is On O7 is On O6 is On O7 is On
		5.13.1.1	In UD1,2 Critical Device Box lift wire 1-3 to lose UD1,2 AC Off status.

AGS-OPM 4.96.2 (Y)

Revision 00

July 15, 1998

	At 5470 box in building 921:		
	Peer 25A O6 and O7 go from ON to OFF		
	Peer 25B O6 and O7 go from ON to OFF		
	Panelview indicates Reach back to AGS Injection		
5.13.1.2	Measure resistance 5470A/13 to K6/9		
	Greater than 100k ohms		
	Measure resistance 5470A/15 to K6/9		
	Greater than 100k ohms		
	Measure resistance 5470A/14 to K11/5		
	Greater than 100k ohms		
	Measure resistance 5470A/16 to K11/5		
	Greater than 100k ohms		
5.13.1.3	Reconnect 1-3 in UD1,2 Box and reset reach back via Panelview and restore mode		
5.13.1.4	In UD1,2 Critical Device Box lift wire 2-3 to lose UD1,2 DC Off status.		
	At 5470 box in building 921:		
	Peer 25A O6 and O7 go from ON to OFF		
	Peer 25B O6 and O7 go from ON to OFF		
	Panelview indicates Reach back to AGS Injection		
5.13.1.5	Measure resistance 5470A/13 to K6/9		
	Greater than 100k ohms		
	Measure resistance 5470A/15 to K6/9		
	Greater than 100k ohms		
	Measure resistance 5470A/14 to K11/5		
	Greater than 100k ohms		
	Measure resistance 5470A/16 to K11/5		
	Greater than 100k ohms		
5.13.1.6	Reconnect 2-3 in UD1,2 Box and reset reach back via Panelview and restore mode		
5.13.1.7	In H10 Critical Device Box lift wire 1-3 to lose H10 Off status. At 5470 box in building 921:		
	Peer 25A O6 and O7 go from ON to OFF		
	Peer 25B O6 and O7 go from ON to OFF		
	Panelview indicates Reach back to AGS Injection		

	5.13.1.8		Measure resistance 5470A/13 to K6/9		
			Greater than 100k ohms Measure resistance 5470A/15 to K6/9 Greater than 100k ohms Measure resistance 5470A/14 to K11/5 Greater than 100k ohms Measure resistance 5470A/16 to K11/5		
		5.13.1.9	Greater than 100k ohms Reconnect 1-3 in H10 Box and reset reach back via Panelview and		
			restore mode		
6.	<u>Documentation</u>				
	6.1	This Procedure c	ompleted.		
	6.2	Completed PASS System Trouble Logbook			
	6.3	Completed PASS	S System Release History Logbook		
7.	Referei	<u>References</u>			
	7.1	AGS OPM 9.1.10	6, "Lockout/Tagout for Radiation Safety (RS LOTO)"		
8.	<u>Attachi</u>	<u>Attachments</u>			